

ADDRESABLE MANUAL CALL POINT

The FGCP100 Manual Call Point is compliant with latest standards and is designed to interface with Fireguard make addressable fire alarm panel. DIP switches are provided for addressing of the call point. The RED blinking LED indicates normal operating condition. Activation of MCP is indicated by RED steady LED, and also a visible YELLOW BLACK strip.

Features:

- EN54-11 Approved Type A Indoor Use.
- Re-Settable by an element kit.
- Suitable for flush or surface mounting
- Module Addressing by 8 way DIP Switches.
- Low Standby Current.

Mechanical Specification

Temperature : 0-49°C.

Relative Humidity : 0- 93%

Connection : 2.5mm²

IP Rating : IP 53



Operating Voltage : 24VDC.

Power-up surge current : 0.8mA

Quiescent Current : 0.5mA.

Alarm Current : 5.8mA

Wiring Diagram

	L1		L1	L1		L1
LOOP	L2	MCP	L2	L2	MCP	L2

Note: L1 and L2 are polarity insensitive, but for the sake of consistency. It's recommend the L2 kept negative